

# RLA UNIGRIP

## Premium Polymer Tile Adhesive C2S2ET



### **DESCRIPTION:**

RLA UNGRIP is a premium grade, Polymer modified, highly flexible white cement-based tile adhesive.

RLA UNGRIP is non-slip/non-slump and is ideal for large format tiles.

RLA UNGRIP is a C2S2ET Adhesive.

RLA UNGRIP is designed for bonding all types of ceramic, stone and mosaic tiles and is ideal for large format tiles onto various substrates like concrete, render, rendered brickwork, blockwork, Gyprock, and fibre cement surfaces. RLA UNGRIP can be used Internally or Externally on wall and floor surfaces.

RLA UNGRIP can be used for fixing Porcelain and Vitrified tiles.

RLA UNGRIP can be used for fixing tiles over most waterproofing membranes. However, it is advisable to contact the manufacturer before commencing.

RLA UNGRIP can be used over some acoustic mats.

RLA UNGRIP is suitable for use over green screeds and concrete.

RLA UNGRIP can be used for fixing tiles in fully immersed situations like swimming pools and spas.

Not suitable for moisture-sensitive stones like green marble or limestones.

### **SURFACE PREPARATION:**

- Ensure all concrete slabs are allowed to cure for at least SEVEN DAY and have a wood float finish.
- All rendered surfaces must be allowed to cure for at least 24 HOURS before commencing tiling.
- The maximum variation in the plane of the concrete must not exceed 5mm in 3 metres for floors and 4mm in 2 metres for walls.
- Steel-trowelled finished concrete surfaces must be mechanically or chemically abraded before commencing tiling.

### **SURFACE PREPARATION:**

#### **CONTINUED:**

- Fibre Cement sheet must be a minimum of 6mm in thickness when used as an underlay material.
- For heavy-duty commercial applications should be a minimum of 9mm thick, and all should be fixed by the manufacturer's instructions and the relevant standards.
- Compressed Fibre-Cement sheets, when used as a floor substrate, must be 15mm thick, and when used as a wall substrate, must be 9mm thick and installed by the manufacturer's instructions and the relevant standards.
- Gypsum-plasterboard sheets must be a minimum of 10mm thick and installed by the manufacturer's instructions and the relevant standards when used as a wall substrate.
- Ensure all surfaces are sound, dry, and free from excessive movement, oil, dust, grease, wax, curing compounds, release agents, paints, and other loose contaminating materials.
- It is recommended that all surfaces be primed with [RLA UNIPRIME](#), particularly on porous surfaces, ensures a good bond of the adhesive to the substrate.
- When applying the primer onto a floor surface, pouring some primer in a section is recommended, then spreading the primer using a broom, brush, or roller. Then continue this method of application until the entire area is primed.

#### **Note:**

This application method ensures a thorough coat of the primer on the surface.

Any excess Uniprime that has not dried should be removed with a rag before tiling.

Allow the primer to dry for approximately.

30 - 40 minutes at 20°C before commencing tiling.



Quality  
ISO 9001



RLA UNIGRIP

RLA Polymers Pty Ltd ACN 004 709 915

215 Colchester Road, Kilsyth, Victoria, 3137 info@rlapolymers.com.au

T. 1800 242 931

[rlapolymers.com.au](http://rlapolymers.com.au)

Version:01

Issue Date 21/10/2022



NANPAO

PART OF THE NAN PAO GROUP

## **MIXING RATIO:**

The mixing ratio of RLA UNGRIP is 15kg of powder to 4.5 litres of water.

Pour 4.5 litres of clean water into a drum and then gradually add the RLA UNGRIP while mixing continuously until a smooth, lump-free mix is obtained.

Always add the powder to the liquid.

Allow the mix to stand for 3 minutes, re-stir and then apply the adhesive onto the substrate.

## **APPLICATION:**

All preparation and tiling should be carried out by

### **AS 3958.1-2007 -Guide to the Installation of Tiles.**

Once the surface has been appropriately prepared per RLA's instructions, apply the adhesive onto the substrate using an appropriate notched trowel.

For the floor and wall tiling, use a 10mm x 10mm square notched trowel for tiles up to 300mm x 300mm.

For tiles 300mm x 300mm and larger, use a 12mm x 12mm square notched trowel and back butter each tile.

Use a 6mm x 6mm square notched trowel for mosaic tiles. For wall tiling, use a 6mm x 6mm square notched trowel for tiles up to 150mm x 150mm. For tiles larger than 150mm x 150mm, use a 10mm x 10mm square notched trowel.

RLA UNGRIP should be applied onto the substrate at a rate of 1m<sup>2</sup> at a time. Application rates greater than this can result in the adhesive skinning before the tiles are laid into it.

Once the adhesive is applied onto the substrate, ensure that it does not skin before bedding the tiles into it. Once the adhesive skins, do not lay tiles into it, but remove it and apply fresh adhesive.

Press the tiles when placed into the adhesive using a sliding action. Ensure no voids occur, and full adhesive coverage is under the tiles.

For tiles with lugs, grooves, or uneven backing, it may be required to butter the back of the tile with adhesive in addition to trowelling the adhesive and the substrate.

The final bed thickness of the adhesive should be at least 2mm for wall tiling and 3mm for floor tiling.

Once the tiling is completed, do not disturb the tiled surface for at least 24 hours at 20°C.

Protect tiling from rain and inclement weather until 24 hours after grouting is complete.

## **EXPANSION / MOVEMENT JOINTS:**

Expansion/movement joints must be provided to allow for movement between adjacent building components. They should be as follows:

- Over Existing joints in the substrate.
- Where two different substrates meet, e.g., Timber and Concrete.
- Around fixed elements on the floor, e.g., Columns.
- At internal vertical corners.
- Around the perimeter of the floor.
- In internal floors where any dimension exceeds 9m or 6m if subjected to sunlight.
- In external floors where any dimension exceeds 4.5 m.
- On wall surfaces at storey heights horizontally and approximately 3m-4.5m apart vertically.
- Ideally, they should be located over movement joints in the structural background and at structural material changes, for example, the horizontal joint at the bottom of floor slabs, vertical joints at internal vertical corners, and junctions with columns.
- Movement joints should go through the tile adhesive bed to the background and be free from dirt and adhesive droppings.
- Movement joints must not be less than 6mm and not wider than 10mm.
- The movement joints must be installed as per AS3958:2007.

## **GROUTING APPLICATION:**

Grouting application can commence after curing for 24 hours at 20°C. Grouting can be done using RLA's Grouts. Wait to allow foot traffic on tiling until 24 hours after the grout has cured.

Follow RLA application instructions.

## **CLEAN UP:**

Excess adhesive from the face of the tiles can be cleaned up with a damp cloth while the adhesive is still wet. The adhesive that has oozed out into the grout joint must be raked out with a knife/spatula etc. Tools and other equipment can be cleaned using water while the adhesive is still wet.

## TECHNICAL DATA:

PRODUCT INFORMATION:	
Colour	WHITE POWDER
Bulk Density (kg/dm <sup>3</sup> )	1.18 +/- 0.05
Shelf life	12 months
Packaging	15kg BAGS
Coverage – 15kg Bag	It will cover approximately 4.5-5m <sup>2</sup> using a 10mm notched trowel.
CLASSIFICATION	C2S2ET ADHESIVE
APPLICATION DATA 23°C AT 50% RH:	
Mixing Ratio	4.5 litres of water per 20kg
Open Time	30 minutes @ 20°C
Adjustment Time	40 minutes @ 20°C
Pot Life	2 hours @ 20°C
Ready for Grouting	24 hours @ 20°C
Light Foot traffic	24 hours
Ready for wet area service	3-4 days

## HANDY TIPS

- Do not apply RLA UNGRIP in temperatures above 40°C and below 5°C.
- RLA UNGRIP cannot be used for fixing tiles directly onto tongue and groove timber flooring.
- RLA UNGRIP, cement-based, is alkaline and may cause dermatitis. It is recommended that applicators wear PVC gloves or similar and safety goggles.
- Contact RLA's Technical Department for detailed advice for applications/situations not mentioned in these instructions,

## SAFETY & HANDLING:

- Do not breathe dust; wear suitable respiratory protection.
- Use in well-ventilated areas.
- Avoid contact with skin and eyes.
- Wear eye protection and suitable gloves and clothing.
- Do not eat, drink, or smoke while using this product.
- Take off contaminated clothing and wash it before reuse.

**The Safety Data Sheet is available upon request.**

## FIRST AID:

- If poisoning occurs, contact a doctor or the Poisons Information Centre.
- If swallowed, DO NOT induce vomiting; give a glass of water and immediately call the Poisons Information Centre and a doctor.
- For advice or if you feel unwell, contact a Poisons Information Centre: Australia ph. 131126, New Zealand ph. 0800 764 766 or a doctor at once.
- If on SKIN, remove all contaminated clothing immediately and wash the skin with soap and water.
- If in EYES, rinse carefully with water for several minutes. Remove contact lenses; if present, then continue rinsing.
- If eye irritation persists, get medical advice/attention.
- If inhaled, remove them to fresh air, and keep them at rest in a position comfortable for breathing.

**WARRANTY STATEMENT:**

RLA Polymers guarantees this product against manufacturing defects and guarantees it to be manufactured to our published specifications.

We certify that this product is suitable for use when fully cured and will perform as described in our technical data sheet or other published materials.

RLA Polymers will replace the product free of charge when purchased from any legally verifiable source and where a product is proven to have been stored, handled, and install according to instructions published on our packaging and within the stated shelf life. The Installation of all materials must be carried out per the relevant Australian Standards.

Warranty doesn't apply if damage, loss, failure to follow instructions, or other circumstances are out of our control.

Sufficient time and access to investigate any complaint must be accorded to RLA Polymers.

The consumer is responsible for any expenses incurred in making a claim.

A claim form can be requested by:

**PHONE:** 1800 242 931

**EMAIL:** [info@rlapolymers.com.au](mailto:info@rlapolymers.com.au)

**MAIL:** 215 Colchester Road Kilsyth Victoria 3137 (Attention Customer Service)

**WEBSITE:** [www.rlapolymers.com.au](http://www.rlapolymers.com.au)

**AUSTRALIAN CONSUMER LAW:**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality, and the failure does not amount to a major failure. The benefits under our warranty are in addition to other rights and remedies available to the consumer under the law in relation to the goods and services to which the warranty relates.

**DISCLAIMER:**

All statements and technical information contained herein are based on tests we believe to be reliable, but the accuracy thereof is not guaranteed.

Users assume all risk and liability resulting from the use of the product and must confirm the suitability thereof by their own tests. Conditions of Sale contain a limited warranty against manufacturing defects.